



**THE MILWAUKEE
PRESERVATION
PORTFOLIO**
MILWAUKEE HISTORIC
PRESERVATION COMMISSION
808 N. BROADWAY
MILWAUKEE, WI 53233
(414) 226-5708

The Spartan
A historic house built in the
early 1800s and restored in the
20th century houses
Model 202-049

Details

*ALL TRIM SHOULD BE CLEAR, SMOOTH WOOD THAT IS FREE OF SAPWOOD AND OF A MODERATE DECAY RESISTANCE. WESTERN REDWOOD, CYPRESS, WHITE OAK, AND MAHOAGANY.


*IF PINE IS USED IT SHOULD BE CLEAR, SMOOTH EASTERN WHITE PINE, WHICH HAS MODERATE DECAY RESISTANCE. WESTERN REDWOOD, CYPRESS, WHITE OAK, AND MAHOAGANY ARE HIGHLY SUSCEPTIBLE TO EARLY DECAY IN AN OUTDOOR INSTALLATION.

*FLAT TRIM AROUND WINDOWS AND DOORS, THE CORNER BOARD, FRIeze BOARDS, AND RANKING CORNICE BOARDS ARE ALL 5/4" THICK.




*PLEASE NOTE THAT QUARTER-SAWN WOOD WILL LAY FLATTER, HOLD PAINT BETTER AND GENERALLY WEAR BETTER THAN PLAIN-SAWN WOOD OF THE SAME SPECIES.

*RADIALLY-SAWN (A TYPE OF QUARTER-SAWN) WOOD IS EASIER TO PRICE AND CLAMPING IS RECOMMENDED.


*RESEARCH HAS SHOWN THAT WHEN NEW, EXTENSION ELEMENTS FOR A PRODUCT ONLY A WEEK OR TWO, THE LIFE OF THE PAINT JOB APPLIED TO IT IS LIKELY TO BE DECREASED. INSTALLATION CAN INCREASE THE LIFE OF THE WOOD AND THE FINAL PAINT JOB.




WATER TABLE
FULL SIZE



CORNER BOARDS
FULL SIZE



WINDOW AND DOOR TOPS
FULL SIZE



THIS MEASUREMENT IS 4-1/2" FOR WINDOW AND DOOR TOPS BUT IS INCREASED TO 5-3/4" OVER THE MAIN OVERHEAD GARAGE DOORING.